




ITEM# PLFT3349BL/PLFT3349RD

Plastic Water Fountain



Please adjust the fountain to create a smooth water fall on the ridges. This can be done by leveling the fountain with pebble or rocks underneath it.

Please NOTE: PUMP must not run dry, or the item can stop working.

XBrand has limited 1 year warranty on all of our products. Please notate on the cord date of purchase with your order number for easily recalling your warranty.



→ PLEASE LET US HELP YOU BEFORE RETURNING TO STORE.

For any questions please email us at info@xbrand.us, or visit us at www.xbrand.us.

WE APPRECIATE YOUR FEEDBACK ONLINE. PLEASE HELP US REVIEW THIS PRODUCT AT YOUR PLACE OF PURCHASE.